

# iCube 3



by Hugo Shelley

Thank you for purchasing iCube 3! This tiny, colourful die contains hidden circuitry that will transmit the value of the uppermost face to your iPhone, enabling a variety of mind-reading effects to be performed.

## CONTENTS

1. iCube 3
2. USB charge cable
3. Magnetic opening tool

## QUICK START

The cube must be charged before use. To open the cube and access the charge port, place the magnetic opening tool on the blue face and lift it off. Insert the charge cable and connect it to a wall adapter, laptop or desktop computer.



Charging may take up to 4 hours if the battery is empty. When full, the blue LED will change from bright to dim. Remove the charge cable.



Turn on the cube by pressing and holding the button until the white LED flashes. Now replace the blue face, allowing it to snap into place.

## THE APP

The iCube Reader app can be found on the app store - just search for 'iCube Reader'. Instructions for connecting to the cube can be found in the help menu.



Once connected, your phone will vibrate when the cube is turned. The default coding is as follows:

1: Green, 2: Orange, 3: White, 4: Yellow, 5: Red, 6: Blue

Note that when your phone is asleep, an extra 'alert' vibration may be added at the beginning of the sequence.

## SWITCHING OFF THE CUBE

The cube can be turned off in two ways - either from the app (Settings > Shutdown iCube) or by physically opening the cube and pressing and holding the button until the white LED flashes once.

## FAQ/TROUBLESHOOTING

*Can I replace the faces?*

Faces can be replaced with any custom-printed 19mm sticker. When replacing the blue face, it is advisable to use a slightly larger sticker and trim down the edges to precisely match the diameter of the steel disc.

*Are wall chargers safe to use?*

Any standard USB charger (and micro-USB charge cable) is safe to use.

*Can the vibration code be changed?*

Yes! The app allows you to reconfigure the vibration for each face.

*Should I fully discharge the battery, or keep it topped up?*


Keeping the battery topped up between performances will extend the lifetime of the battery.

*Is there an Android App?*

Not yet! We'll let you know if one is released.

*I'm having trouble removing the blue face!*

If the face is jammed in position, remove the layer of soft felt from the magnetic tool. This allows it to grip the blue face with significantly more force. Without the felt, extra care must be taken to avoid the magnet from scratching the surface.



Also available:



Sixth Sense 3 is the latest edition of our bestselling magnetic coin sensor



Mind Pad 3 is a new addition to our range of wireless impression pads (available April 2020)



Insight Pro includes a full deck of electronic playing cards and a powerful wireless reader.

## **WARRANTY**

iCube 3 is covered against defects for one year from the original purchase date.

Damage to the circuit board or other components voids the warranty. The cube is designed to last many years, but like any electronic product must be treated with care.